

**NOTE**

Shop Prep. and Pre-fit doors for all parts. Tag by door No. and ship loose with doors.

**CAUTION**

Refer to the shop drawings for door weights. Be sure to use cables, straps, etc. that are rated to handle these weights.

**FIELD INSTALLATION**

After door is hung, remove all lifting brackets and plug holes using 1/2" - 13 x 5/8" long plug installed flush with door face.

